






RO★530

Ersatzteile • Spare parts • Pièces de rechange • Ricambi • Piezas de recambio



Pos		ROE	
01	RO530Axxxx	ROE 71869A	1
01	RO530Bxxxx	ROE 71869B	1
02	RO530Axxxx	ROE 50294	1
02	RO530Bxxxx	ROE 50296	1
03		ROE 71747	1
04		ROE 30269	1
05		ROE 71610	1
06		ROE 71380	1
07		ROE 47081	1
08		ROE 70850	1
09	RO530xxxxxxx0	ROE 53683	1
10		ROE 70948	1

Pos		ROE	
11		ROE 46134	1
12	RO530xxxxxxx0	ROE 71331	1
13	RO530xxxxxxx0	ROE 30486	1
14		ROE 59169	1
15		ROE 25475	1
16		ROE 44159	1
17		ROE 45133	1
18		ROE 59277	1
19		ROE 30365	1
20		ROE 70939	1
21		ROE 30364	1